

Novation PEAK / Summit: Drift Preset Overview

Preset Number	Name	Category
0	Drift	Motion
1	Space	Pad
2	Light	Pad
3	Still	Pad
4	Whisper	Pad
5	Echo	Pad
6	Void	Motion
7	Pulse	Pad
8	Wave	Motion
9	Glow	Pad
10	Float	Motion
11	Calm	Pad
12	Fade	Motion
13	Clear	Pad
14	Soft	Motion
15	Quiet	Pad
16	Dawn	Pad
17	Air	Motion
18	Breeze	Motion
19	Shade	Motion
20	Dream	Lead
21	Flow	Lead
22	Zentaur	Bass
23	Glint	Lead
24	Mutator	Bass
25	Blink	Bass
26	Pure	Bass
27	Dust	Lead
28	Hue	Lead
29	Pitch	Bass
30	Rage	Lead
31	Free	Bass
32	Snow	Lead
33	Bare	Bass
34	Glare	Bass
35	Sway	Arp
36	Grace	Arp
37	Blur	Arp
38	Mist	Arp
39	Stillness	Arp
40	Ether	Arp
41	Chill	Arp
42	Gaze	Arp
43	Glow	Arp
44	Pause	Arp

Preset Number	Name	Category
45	Line	Arp
46	Silver	Arp
47	June	Arp
48	Ecosphere	Arp
49	Whoop	Arp
50	Dub1	Dub Chord
51	Dub2	Dub Chord
52	Dub3	Dub Chord
53	Dub4	Dub Chord
54	Dub5	Dub Chord
55	Dub6	Dub Chord
56	Dub7	Dub Chord
57	Dub8	Dub Chord
58	Dub9	Dub Chord
59	Dub10	Dub Chord
60	Serenity	Bass
61	Clarity	Bass
62	Evoke	Lead
63	Harm	Lead
64	Tranquil	Arp
65	Essence	Motion
66	Silence	Lead
67	Fragments	Motion
68	Infinity	Pad
69	Ghost	Pad
70	Kick	DrumPercussion
71	Prism	SFX
72	Ascend	DrumPercussion
73	Alkaloid	SFX
74	Emerge	SFX
75	ClareTom	DrumPercussion
76	Illuminate	SFX
77	Crash	DrumPercussion
78	Driftwood1	Pad
79	Driftwood2	Motion

